



A. Hard starting

HARD STARTING




ENGINE STALLS DURING OPERATION




B. The engine stalls during operation

THE MOTOR RUNS POORLY

C. The motor runs poorly



INSUFFICIENT OUTPUT



D. Insufficient output